

Installation



Adhesives

Use an adhesive designed for the application of accessories. Adhesive should be a hard-set adhesive that does not allow the material to shrink or expand after installation. Roppe does not recommend the use of "stair tread" installation tape as an adequate adhesive for the installation of Roppe Rubber Accessories. This material can allow the material to shrink or expand and create gapping. It is up to the installer to determine acceptable bond to prevent shrinking and expansion.

Stair Nosings & Landing Trim

Install all Stair Nosings and Landing Trims prior to the installation of flooring materials. Trim accessories with a razor knife and straight edge or a miter saw / radial arm saw with a 60 tooth or greater carbide tipped blade. After fitting accessories, clean the backside with denatured alcohol and a clean white rag to ensure there are no contaminants. It may be necessary for light sanding the back of stair nosings to achieve adequate bond. 5100 Tread Nose Compound is required with all stair nosing installations. Roppe strongly recommends 7200 Urethane Epoxy Adhesive or 5100 Tread Nose Compound be used as the primary adhesive.

Thresholds, Adapters, Transitions, Corner Guards & Cove Caps

Trim accessories with a razor knife and straight edge or a miter saw / radial arm saw with a 60 tooth or greater carbide tipped blade. If installation requires a radius, make sure radius will work prior to the spreading of any adhesive. After fitting accessories, clean the backside with denatured alcohol and a clean white rag to ensure there are no contaminants.

Restrictions after Installation

Spray Adhesive

Immediate foot traffic
Immediate rolling loads

3100 Rubber Tile & Tread Adhesive

Foot traffic after 24 hours

5100 Tread Nose Compound

Foot traffic after 12 hours

7200 Urethane Epoxy Adhesive

Foot traffic after 24 hours

- When moving in appliances or heavy furniture, it is always wise to protect the accessories from scuffing and tears by using something to protect the floor
- Use floor protectors under furniture or fixtures to reduce indentation; as a rule of thumb, the heavier the item the wider the floor protection device needed
- Place walk-off mats at outside entrances manufactured with non-staining backs to prevent discoloration

