



Alpine Industries
27 Selvage St.
Irvington, NJ 07111
Tel: 973 601 5105
Fax: 973 854 8650

Stainless Steel Sanitary Napkin Receptacle

Item# 451-SSB

Installation

1. Please choose a vertical, clean and smooth mounting surface.
2. Make sure there is enough room above dispenser to open the cover.
3. Open the top cover and use the back plate for the drill marks and mark the 2 drill locations.
4. Drill 2 holes.
5. Insert 2 plastic anchors (not supplied) into drilled holes.
6. The installation should be done with a flat washer (not supplied) between the head of the screw and inside back of the dispenser.
7. Insert 2 screws into the 2 holes and leave 1/8" space from the wall under head for hanging dispenser
8. Hang the dispenser on the screws through the keyhole slots at back plate.
9. Tighten the 2 screws.