# CAE2745



# Mechanical Options



### V14 Coin Slide 3.50 Max



### **Electronic Options**



### CxM2745



### **Mechanical Options**











Electronic Options Both needed for Dryer

# Whirlpool Computer Control Options

















\*\*Both the factory installed coin and non-coin models can be wired to accept mobile payment systems\*\*

# Whirlpool Corporation Confidential

# How to direct customer requests

Electronic Service	Compatible WHR platforms	Bullet Points	Installation	Contact
PayRange BluKey	Front Load, Stack Dryer/Dryer, Stack Washer Dryer, Top Load	Device that can be installed to facilitate mobile payments - ONLY (top load matching dryer requires an additional PayRange module) No Wifi	Device install = Plug and Play (connections only) Signage + App Download + Account setup	https://support.pa yrange.com/hc/en -us/requests/new
ShinePay	Front Load, Stack Dryer/Dryer, Stack Washer Dryer	Device that can be installed to facilitate mobile payments - ONLY No Wifi	Device install = Plug and Play (connections only) Signage + App Download + Account setup	510-800-1397 https://shinepay.c o/contact
Kiosoft Ultra LX Pro/Ultra VXT pro	Front Load, Stack Dryer/Dryer, Stack Washer Dryer	Device that can be installed to facilitate mobile payments(Apple Pay/Google Pay), credit card/debit card, & Kiosoft App payments.  Wifi Required	Device install = Hardware installation + Connections  App Download + Wifi Connectivity + Account Setup	1-888-546-7638 https://kiosoft.co m/contact-lp/
ESD Trident	Front Load, Stack Dryer/Dryer, Stack Washer Dryer	Device that can be installed to facilitate mobile payments(Apple Pay/Google Pay), credit card/debit card, & ESD App payments.  Wifi Required	Device install = Hardware installation + Connections  App Download + Wifi Connectivity + Account Setup	1-800-523-1510 https://esdcard.co m/contact-us/
PayRange BluCard Plus -	Front Load, Stack Dryer/Dryer, Stack Washer Dryer	Devices that can be installed to facilitate mobile payments(Apple Pay/Google Pay), credit card/debit card, & PayRange App payments.  Wifi Required	Device install = Hardware installation + Connections  App Download + Wifi Connectivity + Account Setup	https://support.pa yrange.com/hc/en -us/requests/new