



Oxivir® Tb and Oxivir® Tb Wipes

General Virucide,
Bactericide,
Tuberculocide,
Fungicide,
Sanitizer



A ready-to-use cleaner disinfectant based on proprietary AHP® technology to deliver fast, effective cleaning performance.

Effective

- Bactericidal and *Virucidal in one minute, kills HBV, HCV, HIV-1 (AIDS virus) in one minute, Tuberculocidal in five minutes and kills fungi in ten minutes
- Patented technology contains a high performance surfactant system that delivers faster and better cleaning results
- SKU #5388471 meets NFPA (National Fire Protection Association) and CMS (Centers for Medicare & Medicaid Services) requirements

Environmentally Responsible

- No VOC's, no added fragrance, no NPE's
- The active ingredient breaks down to water and oxygen

Easy-to-Use

- Use to clean most hard, nonporous environmental surfaces with confidence
- Non-irritating to skin and eyes and contains no substances which at the given concentration, are considered to be hazardous to health per OSHA standards



Oxivir® Tb and Oxivir® Tb Wipes

General Virucide, Bactericide, Tuberculocide, Fungicide, Sanitizer



Use Directions

- Pre-clean heavily soiled areas.
- Apply solution by cloth or disposable wipe to hard, non-porous environmental surfaces.
- All surfaces must remain wet for one-minute to kill bacteria, HIV-1, HBV and HCV.
- Use a five-minute contact time for Tb and a ten-minute contact time for fungi.
- Wipe surfaces dry, rinse or allow to air dry.
- **Note:** Rinsing is not necessary unless floors are to be coated with finish or restorer. All food contact surfaces must be rinsed with potable water. Do not use on glassware, utensils, or dishes. Not recommended for use on brass, copper, aluminum, bronze, granite, zinc or marble.

Product Specifications

Description	
Color/Form	Colorless, liquid; Colorless, wipe
EPA Reg. No.	70627-56 (RTU) 70627-60 (Wipes)
pH	2.5–3.5
Scent	Characteristic
Solubility	Complete
Shelf Life	2 years (RTU), 3 years (Wipes)
Specific Gravity	1.01

Available Items

Product Code	Description/Package Size	Dilution
4277285	12 x 32 fl. oz. / 946 mL Flip Top Bottles Plus Two Trigger Sprayers	Ready-to-Use
4599516	12 x 160 count 6 x 7 in. Wipes / 15.24 x 17.78 cm Canisters	Ready-to-Use
5388471	12 x 60 count 7 x 8 in. Wipes / 17.8 x 20.3 cm Canisters	Ready-to-Use
5627427	4 x 160 count 11 x 12 in. Wipes / 27.9 x 30.5 cm Buckets	Ready-to-Use
100823906	4 x 160 count 11 x 12 in. Wipes / 27.9 x 30.5 cm Refills	Ready-to-Use
5499664	6 x 1 Unit (Wall Bracket for use with 60 count Canisters)	
9P700798	1 Double Unit Non-Locking Stand	
9P700797	1 Double Unit Locking Stand	
9P700814	1 Plastic Locking Bracket (for use with 160 count Buckets)	
9P700799	6 x 1 Unit Wire Bracket Locking on Plastic Wall Mount (for use with 160 count Buckets)	
9P700800	6 x 1 Unit Wire Bracket Non-Locking on Plastic Wall Mount (for use with 160 count Buckets)	

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up to date shipping information.

AHP and Design® are registered trademarks of Virox Technologies, Inc. used under license.

www.sealedair.com

© 2014 Sealed Air Corporation. All Rights Reserved. 18780-SPC729 en US (14/343)