



HYDRO-BALANCE



NON-ACID HYDRO-KLEEN CONCENTRATE

- Ideal for Cleaning Grease Contaminated Refrigeration Coils & Condensers
- Foams Out Stubborn Deposits from Coils
- Non-Acid Concentrate

DANGER: CORROSIVE. CAUSES SEVERE SKIN BURNS AND EYE DAMAGE. FOR PROFESSIONAL USE ONLY. KEEP OUT OF REACH OF CHILDREN. SEE SIDE PANELS FOR ADDITIONAL PRECAUTIONS.

MIX 1 PART CLEANER TO:

x3 parts water
(heavy duty)

x6 parts water
(medium duty)

x20 parts water
(light duty)

HYDRO-KLEEN is specially formulated for the cleaning and brightening of air conditioning condenser coils. It is non-acidic, non-flammable and contains no toxic petroleum or chlorinated solvents. The surfactants used in HYDRO-KLEEN are biodegradable.

DO NOT USE ON INDOOR COILS. USE ONLY OUTDOORS.

DIRECTIONS FOR USE:

TIP: Cleaning action is accelerated if condenser coil is still warm from use.

1. Read entire label & Safety Data Sheet before use.
2. Disconnect all power before working on equipment.
3. Protect surrounding area from over-spray.
4. Using a suitable low-pressure sprayer, dilute HYDRO-KLEEN with water according to dilution rates below.
5. Always spray downwind with a coarse spray to avoid misting. Spray between fins using horizontal motion, working from the bottom up.
6. Wait 3 to 4 minutes until foam begins to subside and rinse completely with large amounts of water.
7. Flush sprayer completely with water after use.



H-1101, H-1105, H-1155

H-1101, H-1105, H-1155

DANGER: May be corrosive to metals. Causes severe skin burns and eye damage.



Keep in original container. Do not breathe mist, vapors, or spray. Wash face, hands, and any exposed skin thoroughly after handling. Wear protective gloves, protective clothing, and eye/face protection.

FIRST AID: IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so. Continue rinsing. Immediately call a POISON CENTER/Doctor.

Store locked up. Dispose of contents and container in accordance with all local, regional, and national regulations.

Contains [CAS]: Potassium hydroxide [1310-58-3], sodium hydroxide [1310-73-2], sodium silicate [1344-09-8].

FOAM ACTION

EASY RINSE

SPRAY APPLICATION

Similar Coil Cleaners Found
on HydroBalance.com



Made in U.S.A.
HYDRO-BALANCE CORP.
519 Huffines Blvd., Lewisville, TX U.S.A.
(800) 527-5166 (972) 394-9422
www.HydroBalance.com