



Oxivir® Tb

General Virucide,
Bactericide,
Tuberculocide,
Fungicide,
Sanitizer



A ready-to-use cleaner disinfectant based on proprietary AHP® technology to deliver fast, effective cleaning performance.

Features

- One-step cleaner disinfectant
- Powered by AHP® technology
- No VOCs, no added fragrance and no NPEs
- Environmentally responsible – active ingredient breaks down to oxygen and water

Benefits

- Effective against key pathogens – TB, MRSA, Norovirus and VRE
- Kills HBV, HCV and HIV in 1 minute. Tuberculocidal in 5 minutes and Fungicidal in 10 minutes
- Compatible with most hard, non-porous surfaces
- 30 second soft-surface sanitizer

Applications

- Clean and disinfect high-touch surfaces in just ONE Minute
- Non-irritating to eyes and skin



Oxivir® Tb

General Virucide, Bactericide, Tuberculocide, Fungicide, Sanitizer



Use Directions: As a One-Step Cleaner Disinfectant

1. Pre-clean heavily soiled areas.
2. Apply product by coarse trigger spray to hard, non-porous inanimate surfaces.
3. All surfaces must remain visibly wet for 1 minute. Use 5-minute contact time for TB and a 10-minute contact time for fungi.
4. Wipe surfaces dry, rinse, or allow to air dry.

Note: Rinsing is not necessary unless floors are to be coated with finish or restorer. All food contact surfaces must be rinsed with potable water. Do not use on glassware, utensils, or dishes.

Prior to first use on a particular surface, it is recommended to test in a small, discreet area if there is concern of incompatibility, or contact a Diversey Care representative.

To Spot Sanitize Soft Surfaces

1. Remove gross filth prior to sanitization.
2. Hold bottle upright 6" – 8" from surface.
3. Spray until fabric is wet. **DO NOT SATURATE.** Allow surface to remain wet for 30 seconds.
4. Gently blot with a clean, damp, color safe cloth and/or let air dry. For difficult odors or heavy fabrics, repeat application.

Product Specifications

Description	
EPA Reg. No.	70627-56
Color/Form	Colorless, liquid
pH	3
Scent	Characteristic
Shelf Life	2 years

Available Items

SKU Code	Description/Package Size	Dilution
4277285	12 x 32 fl. oz. / 946 mL Flip Top Bottles Plus Two Trigger Sprayers	Ready-to-Use
100898636	4 x 1 gal./3.78 L Containers	Ready-to-Use

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up to date shipping information.

AHP® and Design® are registered trademarks of Virox Technologies, Inc. used under license.